



**Tiger 6100 Series Marine Intercom System
Marine Belt Station Functions/System
diagram**

<i>ICS/Radio Rocker Switch</i>	<i>PTT #</i>	<i>PTT Button Function</i>	<i>Audio Signals the Station Will Hear</i>
ICS	1	Enables User to Speak Over ICS Using PTT Switch; No Ship Radio	ICS, Ship Radio and Portable Radio
Radio	1	Enables Hot Mic On ICS; Enables PTT TX Over Ship Radio	ICS, Ship Radio and Portable Radio
Any Position	2	Enables PTT TX Over Portable Radio	ICS, Ship Radio and Portable Radio

Belt Station Function When Connected to an Intercom System

<i>VOX On/Off Switch</i>	<i>PTT#</i>	<i>PTT Button Function</i>	<i>Audio Signals the Station Will Hear</i>
OFF	2	Enables User TX Over Portable Radio	Portable Radio
On	NA	Enables User To TX In VOX Mode Over Portable Radio (If Equipped)	Portable Radio

Belt Station Function When Dis-Connected From an Intercom System

System Overview

